



PLEASE RINSE EACH NIGHT WITH H2O

- Adjustable cone tips are available
- Extra jugs available for different solutions
- Never wash out a tank again

Please Scroll Down to view Part Numbers & Descriptions

To service the SPRAY1: Unplug from electrical outlet. Remove the 3 black nylon buttons from the bottom of the housing (they are reusable) with a straight blade screw driver. Carefully remove the bottom of the housing with screwdriver.

#	Part Number	Description
*	SPRAY1WAND	Complete Wand(1-4) 8004 Stainless Steel Vjet Tip
1	H1/8VV-SS8004	8004 Stainless Steel V-Jet (8004 or 5001 Brass \$5.42)
2	66CA-4-2	Brass Comp.1/8"female
3	SS18	Stainless tube(15")
4	68CA-4-4	Brass Comp. 1/4"male
5	6590	Brass/SS, Trig/valve(kit bel.)
6	H14-2MUSBR	Brass Compression and Strain Relief
7	FW-6	6 Ft. Coil Hose, 1/4" I.D., includes #H14-2MUSBR
8	SNP-2	Snap Clamp
9	TE-2024	Nylon Barb(st) inc. w/pump
10	508-224	50 psi pump, 115V, viton seals, includes barbs
11	TA-1024	Nylon Barb(90)inc. w/pump
12	NA-22	Polyurethane Hose 1/4" I.D., includes strainer and cap/grommet
13	13862-50	Brass/SS Strainer
14	1G	1 Gallon Container
15	SR7W-2	Power Cord Relief Grom.
16	CORD30	30 Ft. Power Cord
17	1600ORANGE	Lighted Switch
18	VEL	2 Inch Velcro Ret. Band
19	11375K35	Cap with grommet
*	ARD	Black nylon buttons
*	6590-ORING	Valve Repair O RING only