

ALWAYS PLUG IN THE TC BETWEEN JOBS. THE #B924 GEL CELL LEAD ACID BATTERY ALWAYS WANTS TO HAVE A FULL CHARGE. LEAVING THE #B924 HUNGRY SHORTENS ITS LIFE. IT IS IMPOSSIBLE TO OVERCHARGE THE #B924. DO YOU WANT THE OPTION TO CHARGE THE TC IN THE SHOP? RADIO SHACK SELLS A BASEBALL SIZED AC TO DC CONVERTER WITH A CIGARETTE LIGHTER ORIFICE FOR ABOUT \$30. PART # 22-165.

- TC1 & TC2 charge with 8 foot cord #8LEVCORD using round plug starting Jan. 2007 (older style #8CORD has rectangular plug into TC) which plugs into connector attached to 20 foot truck wiring (#F49) which is connected to truckmount or vehicle battery. TC1CIG & TC2CIG charge with (now 18 foot) cord plugged into cigarette lighter #16LEVCIG using roung plug #LEV-M starting Jan. 2007
- For TC1 /TC2: Fuselink (green) must be installed on red wire at source charging battery
- TC1 & TC1CIG have carpet wand only.
- TC2 & TC2CIG have carp. & uphol. wands on QC's.
- Parts #5 and #14 on TC2 & TC2CIG models only.
- For wand parts detail see Model "M" parts diagram

Please Scroll Down to view Part Numbers & Descriptions

Rinse briefly at days end with fresh water for longer pump life. Also rinse with fresh water immediatley after using diluted solvents. Weekly spray of 50-50 mix of isopropyl alcohol & water also helps clean carpet protector deposits from pump.

******FOR NEW JUG QC SYSTEM SEE "M" PARTS PAGE OF THIS WEBSITE*******

<u>#</u>	Part Number	<u>Description</u>
5	BST-1YSS	Stainless Steel Female QC(viton) (Brass Female QC is \$8.17)
6	6590	Trigger Valve, Brass/SS, (viton)
*	6590-ORING	Trigger Valve Repair O RING only (viton)
7	H142MUSBR	Brass compression & strain relief
8	FW-10	Coil Spray Hose 1/4" I.D.(or) includes # H142MUSBR
8	801-4-10	Straight Spray Hose 1/4"I.D., includes hose barb, spring guard & clamp
9	SNP-2	Nylon Hose Clamp
11	N4MEB6	Nylon Elbow, 3/8 NPT
12	AQ12	Aquatec # 58-MUL-828DB66, 12 Volt Motor/pump, 50 psi

13	LEV-M	Panel Connector on back of TC (Round as of Jan. 2007) Large curved lug is positive.		
13*	IEC320	Panel Connector on back of TC (rectangular - before 2007) Red washer marks positive post.		
14	216P-4-2	Brass Reducing Nipple		
15	11375	Rubber Hose Grommit		
16	6.5SS	SS threaded rod + 2 nuts (hold down motor) (need two)		
*	D690 MINDIO6	Diode - allows recharge current into #B924 battery, but not out to run truck accessories. After 2011 TC w/fusebox use # MINDIO6 at \$21.67		
17	12V1M9	Red Illiminated ON/OFF Switch		
18	801-4-46	Suction Hose, 46", 1/4" I.D., inc. strain (for new jug QC, tubes see "M" parts)		
19	13862-50	Suction Hose Strainer, Br/SS		
20	9600K35	Cap with Grommet (old design)		
21	B924	12 Volt, 9 Amp Hour Battery (<u>9 amphour and fresh</u>) Ask your distributor for B924 batteries from Multi-Sprayer. When replacing battery, slightly re-squeeze female electrical leads with a pliers before sliding male/female together! Loose leads hamper full charging.		
22	2G	Solution Container (2 gallon) shipping can increase jug cost substantially		
*	F-49	Truck Plug, 20' wiring includes fuselink (on TC1/TC2)		
*	8LEVCORD	Charging Cord, 8 Feet, round plug. For charging Sears TC set up from van wall (oval plug-in) to TC.		
*	16LEVCIG	Charging Cord, 18 Feet, round plug. For charging TC1CIG & TC2CIG from cigarette lighter plug-in to TC		
*	Fuse10	10 Amp Fuse / Motor (red) After 2011 use # MINF10 in fusebox		
*	CB20	20 Amp Circuit Breaker(2 blades on one side) If the #CB20 is defective, the sprayer will not run and will not charge. Replace every 3-4 years. (Make sure elec. leads are tight) # MINCB25 after 2011 use in mini fuse box		
*	Fuselink	6" Green, must be first on # F-49 (on TC1/TC2) Not on cigarette lighter charge sprayer.		
********************WANDS AND PUMP PARTS LIST PRICES SHOWN UNDER MODEL "M" PARTS ************************************				

AQUATEC 12 VOLT PUMP PARTS SHOWN UNDER "M" PARTS

Cart 2000-227-43 2 Wheel Cart for M, TC and SC Models

Internal Wiring Diagram for TC 12 volt - RED SWITCH = 12V1M9 Black Red Circuit Breaker CB20 Black (-) Diode - D690 Black RED (+) Battery B924 Motor -12V 58MUL828DB66 CHARGE CONNECTOR Black Black 7.5 amp brown fuse on orange wire Notes - Diode to be connected with off center tab closest to Charge Connector-see diag. Please call 800-669-2469 with questions - thank you